

POLARIS RANGER MIRROR INSTALLATION INSTRUCTIONS

Installing SIDE View mirrors on your Spike Ranger doors is very easy. ALL SPIKE Ranger doors feature a built-in mirror bracket on each door just above the door handle, and side view mirrors can easily be attached to this mount. There are many brands of mirrors that will fit, and Spike has a very nice set of mirrors, part number 31012, that come with brackets to mount to the Polaris Pro-Fit tubing. You will NOT use the frame clamps as the mirrors will be attached directly to the door frame. When the doors are removed for the summer, you will then use the supplied brackets and mount the mirrors directly to the tubing.

1. The first step is to locate the mirror mounting plate which is just above the outer door handle and find the hole from the outside of the installed door...this is easily felt through the door fabric.
2. Next, use a hot soldering iron and burn through the outer door fabric ONLY. Do NOT burn through the inner door fabric.
3. Unzip the window (this lessens tension on the smaller zipper that attaches the skin to the frame) and unzip the smaller zipper to access the frame mounting plate. Insert the mirror mounting bolt into the hole in the frame bracket and through the new burned hole in the outer canvas and attach the mirror.
4. Position the mirror and tighten securely. Zip the small zipper and then zip up the window and the job will be completed!

